

# R801T-DZ Stocking Parts List

## Stocking Parts: Electrical Group (1)

No.	Notes	MODEL	R801T	R801T	R801T	R801T	R801T
		INPUT	050	075	075	100	125
		AIRFLOW	3	3	5	5	5
		DESIGN SERIES	A	A	A	A	A
		CABINET WIDTH	14	17	21	21	24
		CONFIGURATION	DZ	DZ	DZ	DZ	DZ
14	Stk	Pressure Switch	42-106205-01	42-106205-01	42-106205-01	42-106205-01	42-106205-01
16	Stk	Limit - Main Limit (Heat Exchanger Panel)	47-25349-07	47-25349-13	47-25349-16	47-25349-02	47-25349-02
17	Stk	Limit - Manual Reset (Burner Compartment)	47-22861-03	47-22861-03	47-22861-03	47-22861-03	47-22861-03
18	Stk	Limit - Heat Assisted (Blower Housing)	47-22860-01	47-22860-06	47-22860-06	47-22860-06	47-22860-06
19	Stk	Transformer w/Fuse	46-24124-03	46-24124-03	46-24124-03	46-24124-03	46-24124-03
20	Stk	Induced Draft Blower (IDB) w/Gasket	70-101087-01	70-101087-01	70-101087-01	70-101087-01	70-101087-01

## Stocking Parts: Blower Group (1)

No.	Notes	MODEL	R801T	R801T	R801T	R801T	R801T
		INPUT	050	075	075	100	125
		AIRFLOW	3	3	5	5	5
		DESIGN SERIES	A	A	A	A	A
		CABINET WIDTH	14	17	21	21	24
		CONFIGURATION	DZ	DZ	DZ	DZ	DZ
21	Stk	Blower Assembly - Includes items 22-25 and Motor Wiring Harnesses	AS-105500-15*	AS-105809-36	AS-105809-37*	AS-105809-38*	AS-105809-39*
25	Stk	Blower Wheel	70-22683-01	70-24254-02	70-23111-20	70-23111-20	70-23111-20
23	Stk	Blower Motor	51-106541-19*	51-106542-24*	51-106542-25*	51-106542-26*	51-106543-28*

## Stocking Parts: Heat Exchanger-Burner Group, Gas Controls (1)

No.	Notes	MODEL	R801T	R801T	R801T	R801T	R801T
		INPUT	050	075	075	100	125
		AIRFLOW	3	3	5	5	5
		DESIGN SERIES	A	A	A	A	A
		CABINET WIDTH	14	17	21	21	24
		CONFIGURATION	DZ	DZ	DZ	DZ	DZ
		EMISSIONS	N	N	N	N	N
27	Stk	Heat Exchanger Assembly - NOX	AS-66997-13	AS-100561-02	AS-66997-24	AS-66997-17	AS-66997-18
32	Stk	Burner Assembly - NOX 80+ (Burner, Support, Cover and Bottom Plates, Ignitor Bracket)	AS-104944-31*	AS-104944-32*	AS-104944-32*	AS-104944-33*	AS-104944-34*
35	Stk	Manifold (w/o Orifices)	81-102427-01	81-102427-02	81-102427-02	81-102427-03	81-102427-04
36		Burner Orifice - Natural Gas	See Orifice Selection Chart				
36		Burner Orifice - LP	See Orifice Selection Chart				
No.	Notes	MODEL	R801T	R801T	R801T	R801T	R801T
		INPUT	050	075	075	100	125
		AIRFLOW	3	3	5	5	5
		DESIGN SERIES	A	A	A	A	A
		CABINET WIDTH	14	17	21	21	24
		CONFIGURATION	DZ	DZ	DZ	DZ	DZ
		EMISSIONS	S	S	S	S	S
27	Stk	Heat Exchanger Assembly	AS-66997-11	AS-100561-01	AS-66997-22	AS-66997-04	AS-66997-05
32	Stk	Burner Assembly (Burner, Support, Brackets, Cover and Bottom Plates, Ignitor Bracket)	AS-104944-21*	AS-104944-22*	AS-104944-22*	AS-104944-23*	AS-104944-24*
35	Stk	Manifold (w/o Orifices)	81-102427-01	81-102427-02	81-102427-02	81-102427-03	81-102427-04
36		Burner Orifice - Natural Gas	See Orifice Selection Chart				
36		Burner Orifice - LP	See Orifice Selection Chart				
No.	Notes	MODEL			R801T		
		GAS CODE			JX		
37	Stk	Gas Valve - Natural Gas			60-103901-02		
37	Stk,1	Gas Valve - LP			See Note 1		
38	Stk	Integrated Furnace Control Board (IFC)			62-105217-01		
39	Stk	Flame Sensor			62-23543-01		
40	Stk	Ignitor			62-24164-04		
		<b>LP Conversion Kit:</b>					
	Stk	LP Conversion Kit			FP-15		