

R802V-UH Stocking Parts List

Stocking Parts: Electrical Group (1)

No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION	R802V	R802V	R802V	R802V
			050 3 A 14 UH	075 4 A 17 UH	075 5 A 21 UH	100 4 A 17 UH
20a	Stk	Pressure Switch Assembly	42-106209-01	42-106209-01	42-106209-01	42-106209-01
22	Stk	Limit - Main Limit (Heat Exchanger Panel)	47-104990-01	47-104990-04	47-104990-04	47-104990-04
23	Stk	Limit - Manual Reset (Burner Compartment)	47-22861-03 (2)	47-22861-03 (2)	47-22861-03 (2)	47-22861-03 (2)
23a	Stk	Limit - Heat Assisted (Blower Housing)	47-22860-06	47-22860-06	47-22860-06	47-22860-06
24	Stk	Transformer	46-24124-06	46-24124-06	46-24124-06	46-24124-06
25	Stk	IDB - Induced Draft Blower (with Gasket)	70-101888-01	70-101888-01	70-101888-01	70-101888-01
No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION	R802V	R802V	R802V	R802V
			100 5 A 21 UH	125 5 A 24 UH	150 5 A 24 UH	
20a	Stk	Pressure Switch Assembly	42-106209-01	42-106209-01	42-106209-01	
22	Stk	Limit - Main Limit (Heat Exchanger Panel)	47-104990-08	47-104990-04	47-104990-04	
23	Stk	Limit - Manual Reset (Burner Compartment)	47-22861-03 (2)	47-22861-03 (2)	47-22861-03 (2)	
23a	Stk	Limit - Heat Assisted (Blower Housing)	47-22860-06	47-22860-06	47-22860-06	
24	Stk	Transformer	46-24124-06	46-24124-06	46-24124-06	
25	Stk	IDB - Induced Draft Blower (with Gasket)	70-101888-01	70-101888-02	70-101888-02	

Stocking Parts: Blower Group (1)

No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION	R802V	R802V	R802V	R802V
			050 3 A 14 UH	075 4 A 17 UH	075 5 A 21 UH	100 4 A 17 UH
31b	Stk	Blower Wheel	PD703025	PD703026	PD703026	PD703026
32	Stk	Blower Motor	51-108481-01	51-108482-01	51-108483-01	51-108482-01
	Stk	Belly Band Motor Mount Kit (includes Motor Mount Arms, Belly Band and Mounting Hardware)	AS-53148-91	AS-53148-91	AS-53148-91	AS-53148-91
No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION	R802V	R802V	R802V	R802V
			100 5 A 21 UH	125 5 A 24 UH	150 5 A 24 UH	
31b	Stk	Blower Wheel	PD703028	PD703028	PD703028	
32	Stk	Blower Motor	51-108482-01	51-108482-01	51-108483-01	
	Stk	Belly Band Motor Mount Kit (includes Motor Mount Arms, Belly Band and Mounting Hardware)	AS-53148-91	AS-53148-91	AS-53148-91	

Stocking Parts: Heat Exchanger-Burner Group, Gas Controls (1)

No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION EMISSIONS	R802V	R802V	R802V	R802V
			050 3 A 14 UH N	075 4 A 17 UH N	075 5 A 21 UH N	100 4 A 17 UH N
40	Stk	Heat Exchanger Assembly	AS-61579-14	AS-100560-01	AS-61579-12	AS-61579-07
42a	Stk	Burner	AS-60993-12*	AS-60993-13*	AS-60993-13*	AS-60993-14*
		Burner Orifice - Natural Gas	See Orifice Selection Chart			
		Burner Orifice - LP	See Orifice Selection Chart			
No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION EMISSIONS	R802V	R802V	R802V	R802V
			050 3 A 14 UH S	075 4 A 17 UH S	075 5 A 21 UH S	100 4 A 17 UH S
40	Stk	Heat Exchanger Assembly	AS-61579-14	AS-100560-01	AS-61579-12	AS-61579-07
42a	Stk	Burner	AS-60993-12*	AS-60993-13*	AS-60993-13*	AS-60993-14*
		Burner Orifice - Natural Gas	See Orifice Selection Chart			
		Burner Orifice - LP	See Orifice Selection Chart			

No.	Notes	MODEL GAS CODE	R802V KP			
50	Stk	Gas Valve - Natural Gas	60-101921-01			
	Stk,2	Gas Valve - LP	See Note 2			
51	Stk	M1 2-Stage Furnace Control (IFC)	62-108462-01*			
52	Stk	Flame Sensor	62-23543-01			
53	Stk	Spark Ignitor	62-24164-05*			
	Stk	LP Conversion Kit - U.S./Canadian Models	FP-32			

Stocking Parts: Heat Exchanger-Burner Group (2)

No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION EMISSIONS	R802V	R802V	R802V	
			100 5 A 21 UH N	125 5 A 24 UH N	150 5 A 24 UH N	
40	Stk	Heat Exchanger Assembly	AS-61579-04	AS-61579-05	AS-61579-06	
42a	Stk	Burner	AS-60993-14*	AS-60993-15*	AS-60993-16*	
		Burner Orifice - Natural Gas	See Orifice Selection Chart			
		Burner Orifice - LP	See Orifice Selection Chart			
No.	Notes	MODEL INPUT AIRFLOW DESIGN SERIES CABINET WIDTH CONFIGURATION EMISSIONS	R802V	R802V	R802V	
			100 5 A 21 UH S	125 5 A 24 UH S	150 5 A 24 UH S	
40	Stk	Heat Exchanger Assembly	AS-61579-04	AS-61579-05	AS-61579-06	
42a	Stk	Burner	AS-60993-14*	AS-60993-15*	AS-60993-16*	
		Burner Orifice - Natural Gas	See Orifice Selection Chart			
		Burner Orifice - LP	See Orifice Selection Chart			